1) Power on the MP3 player, then navigate using the Mode button left or right, go to Music mode, see picture below



2) While in Music mode, shortly press the Mode button, the it will bring you to submenu, see picture below.



3) While in submenu, press the play/pause button to pause the music that is currently playing, see picture below



4) Now that the music is pause shortly press the mode button, this will bring you to the submenu



5) While in browse submenu, shortly press the mode button again, this will bring you to the folder you make, see picture below



6) to highlight the folder you want to play, use the left or right function of the mode button, then once you highlighted the folder you want, press the play/pause button this will bring you to the music playing, see picture below



Note that it will play all the music on that particular folder. You cannot browse each music on that folder, you try that you will only see folder and dot dot dot.